

Cuisinart®

INSTRUCTION BOOKLET



Automatic Cold Brew Coffeemaker

DCB-10C

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be taken, including the following:

1. **READ ALL INSTRUCTIONS.**
2. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. To unplug, grasp plug and pull from electrical outlet. Never pull cord.
3. To protect against electrical shock, do not put the motor body, cord or electrical plug of this coffeemaker in water or other liquids. Never submerge any other portion of this unit. If the coffeemaker falls into liquid, unplug the unit first, then remove coffeemaker immediately. **Do not reach into the liquid without unplugging the unit first.**
4. This appliance should not be used by children. To avoid possible accidental injury, close supervision is necessary when any appliance is used by or near children or individuals with certain disabilities.
5. Avoid contact with moving parts. Keep hands, hair and clothing, as well as utensils from unit away from unit during operation to reduce the risk of injury and/or damage to the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance has malfunctioned or has been dropped or damaged in any way or dropped into water. Return the appliance to the nearest Cuisinart Repair Center for examination, repair, or mechanical or electrical adjustment.
7. The use of attachments or accessories not recommended by Cuisinart may cause fire, electrical shock, or risk of injury.
8. Do not use outdoors, or for other than its intended use.
9. Do not let any cord hang over the edge of the table or counter. Do not let cord contact hot surfaces, including stovetop.
10. Make sure the appliance is off, the motor has stopped completely, and the appliance is unplugged from outlet before putting in or taking out removable parts, and before cleaning.
11. Be certain the lid is securely in place before operating appliance.
12. Do not operate your appliance in an appliance garage or under a wall cabinet. **When storing in an appliance garage, always unplug the unit from the electrical outlet.** Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.
13. Never pour water into the unit unless the removable water tank is securely in place.
14. Always fill water tank first,* then plug cord into the wall outlet. To power off, remove plug from wall outlet.
15. This appliance is for household use. Any servicing other than cleaning and user maintenance should be done only by authorized Cuisinart Repair Personnel.
16. Make sure carafe lid is secure before serving any beverages.
17. Do not use a cracked carafe or a carafe having a loose or weakened handle.
18. Do not clean carafe or resting plate with harsh cleansers, steel wool pads, or other abrasive materials.
19. **WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT REMOVE THE BASE PANEL. NO USER-SERVICEABLE PARTS ARE INSIDE. REPAIRS SHOULD BE DONE ONLY BY AUTHORIZED PERSONNEL.**
20. Use only the included Cuisinart® Stainless Steel Coffee Filter Basket and Stainless Steel Carafe Lid Filter, which are specially designed for this unit. Other filters will not work.
21. Do not operate unless all removable parts are securely in place.

* Use only cold or room temperature water.

Never use hot water.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

WARNING: RISK OF FIRE OR ELECTRIC SHOCK



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated, dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of fire or electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

SPECIAL CORD SET INSTRUCTIONS

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord. Longer extension cords may be used if care is exercised in their use.

NOTICE

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

CAUTION

- Do not immerse base in water.
- To reduce the risk of fire or electric shock, do not disassemble the base.
NOTE: The base does not contain any user-serviceable parts.
- Repairs should be made only by authorized personnel.
- Check voltage to be sure that the voltage indicated on the name plate agrees with your voltage.
- Never clean with scouring powders or hard, abrasive implements.

	WARNING	
RISK OF FIRE OR ELECTRIC SHOCK DO NOT OPEN		
WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REPAIRS SHOULD BE DONE BY AUTHORIZED SERVICE PERSONNEL ONLY		

CONTENTS

Important Safeguards	2
Important Unpacking Instructions	4
Features and Benefits	5
Getting to Know Your Control Panel.	6
Before Brewing Your First Pot.	7
Making Coffee	7
Cleaning and Maintenance	9
Troubleshooting	10
Warranty.	11

IMPORTANT UNPACKING INSTRUCTIONS

1. Place the box on a large, sturdy, flat surface.
2. Remove literature.
3. Turn the box so that the back side of the coffeemaker is down and slide the coffeemaker from the box.
4. After the coffeemaker has been removed, place the box out of the way and lift off the left and right inserts.
5. Grasp the carafe by its handle, remove it from the base, and remove the polybag.
6. Remove the polybag covering the coffeemaker.

Save all packing materials in case you have to ship the machine in the future.

KEEP ALL PLASTIC BAGS AWAY FROM CHILDREN.

COLD BREW COFFEE.

THE PERFECT BALANCE.

ELEMENT 1: WATER

Coffee is 98% water. The quality of that water is as important as the quality of your coffee. If water doesn't taste good from the tap, it won't taste good in your coffee. It is suggested that filtered water be used to achieve the purest coffee flavour, every time you brew.

ELEMENT 2: TEMPERATURE

The cold brew process never exposes coffee to high temperatures. Instead, coffee is brewed using cool water, which extracts less of the acidic oils that can cause coffee flavour to be a little bitter. The result of cold brewing is a naturally smooth, perfectly balanced cup of coffee.

ELEMENT 3: COFFEE

While coffee is 98% water, all of the flavour comes from the beans. Once the bean is broken, its flavor degrades quickly. To achieve the same great taste you enjoy at a coffee bar, buy only a two-week supply of fresh coffee beans at a time.

ELEMENT 4: PROPORTION

Coffee that is too strong or too weak is always a disappointment. Follow the recommended recipe in the instructions under MAKING COFFEE, and later adjust the amount to your taste.

FEATURES AND BENEFITS

1. Coffeemaker Lid

Lifts off to access Coffee Filter Basket and Water Tank.

2. Coffee Filter Basket

Lifts out of Water Tank to fill and clean.


2a. Pop-Off Lid

2b. Twist-Off Lid

3. Removable Water Tank (with water level markings)

Removes from unit for easy filling and cleaning.

NOTE: NEVER POUR WATER DIRECTLY INTO THE BODY OF THE UNIT UNLESS THE WATER TANK IS SECURELY IN PLACE.



4. Removable Water Tank Filter

5. Coffee Release Lever

See detailed illustration, page 6.

6. Blue Coffee Release Indicator Light

7. Control Panel

See detailed illustration, page 6.

8. 7-Cup Glass Carafe

The easy-pour carafe has an ergonomic handle and coffee markings for 3 to 7 cups. Can be used to store coffee in the refrigerator.

8a. Carafe Lid

8b. Carafe Filter

Removes from lid for easy cleaning.

9. Ready Tone Alert (not shown)

Beeps 3 times when brew cycle is completed and coffee is ready to be released into the carafe. Beeps 5 times when coffee is fully released into carafe and is ready to be served.

10. 60-Second Reset (not shown)

One-minute protection in case a breaker trips, the unit is unplugged, or the power fails. Retains all programmed information.

11. Measuring Scoop


12. BPA Free (not shown)

All parts that come in contact with coffee or liquids are BPA free.



GETTING TO KNOW YOUR CONTROL PANEL

Detailed programming and use instructions are on pages 7–8.



1. Brew Button

Starts and stops brew cycle.

2. Strength Buttons

Choose Mild, Medium or Bold coffee flavour; white indicator illuminates selected strength.

NOTE: The default setting is Medium.

3. Coffee Release Lever

3a. Lock Position

Lever must be in this position to begin brew cycle. Blue indicator light will be off when lever is in this position.

3b. Release Position

Slide lever to this position for coffee to flow into the carafe after the brew cycle has been completed. Blue indicator

light will illuminate when lever is in this position.

NOTE: Always slide lever back to the Lock position after coffee has been filtered into the carafe, so the coffeemaker is ready for the next brew.

4. Blue Coffee Release Indicator Light

Illuminates when the Coffee Release Lever is in the Release position. The indicator light will remain on until the lever is returned to the Lock position.

BEFORE BREWING YOUR FIRST POT OF COFFEE

Rinsing your coffeemaker: During the manufacturing process, dust can get trapped in the unit. We recommend washing all parts of the coffeemaker before the first use. See Cleaning and Maintenance on page 9 for detailed instructions.

HELPFUL HINTS

- **Always keep Coffee Release Lever in the Lock position when the coffeemaker is not in use.**
- Use a dark roast, medium-to-coarse grind for optimal flavour.
- For best results, use filtered cold water to fill the water tank.

MAKING COFFEE

Recommended Recipe		
Ground Coffee	Total Water	Brewed Cups
5½ level scoops	15 oz. / 470 ml	3
9 level scoops	25 oz. / 790 ml	5
13 level scoops	35 oz. / 1.1 L	7

NOTE: Adjust amount according to taste. One level scoop is equal to one tablespoon (15 ml). Do not fill past the MAX level marking, 16 level scoops/16 tablespoons (240 ml), as it may not fully absorb the water.

1. Add the ground coffee

Lift off the coffeemaker lid to access the coffee filter basket. The coffee filter basket may be filled one of two ways.

- a. Leave the coffee filter basket positioned in the water tank and remove the pop-off lid. Use the included measuring scoop to add ground coffee. See recommended recipe above. Replace pop-off lid.



- b. Remove the coffee filter basket from the water tank and unscrew the twist-off lid. Use the included measuring scoop to add ground coffee. See recommended recipe. Replace twist-off lid and turn clockwise 1½ times to secure lid. Position the coffee filter basket into the water tank and push down until clicked into place. Replace coffeemaker lid.



NOTE: If the coffee filter basket is not securely positioned in the water tank, the coffeemaker lid will not fit properly.

2. Fill the water tank

IMPORTANT NOTICE: ALWAYS MAKE SURE THE RELEASE LEVER IS IN THE LOCK POSITION BEFORE FILLING THE WATER TANK TO PREVENT WATER FROM FLOWING OUT.

NEVER FILL USING HOT WATER.

Slowly pour the desired amount of cold water into the water tank, using the water level indicators located on the backside of the water tank.



Use the water level indicator **WITH COFFEE BASKET** when ground coffee has been added to coffee filter basket and is positioned in the water tank. Use the water level indicator **WITHOUT COFFEE BASKET** when coffee filter basket is not positioned in the water tank.



NOTE: The water tank may be removed to fill. Use the handle to remove water tank from the unit. Slowly pour the desired amount of cold water into water tank and place securely back into the unit. Replace coffeemaker lid. **NEVER POUR WATER DIRECTLY INTO THE BODY OF THE UNIT WITHOUT THE WATER TANK SECURELY IN PLACE.**



3. Position carafe and plug in unit

Insert carafe lid and filter into the carafe and place carafe on the resting plate. Plug coffeemaker into an electrical outlet. If the

coffeemaker remains untouched for 30 minutes, it will enter standby mode and all lights will be off. Press any button to wake up the unit.

4. Set strength preference

The default strength setting is Medium. Press Mild or Bold button to change selection. The LED on the selected strength button will illuminate.

NOTE: The brew time varies according to the strength selected. See times below:

Strength	Brew Time
Mild	25 Minutes
Medium	35 Minutes
Bold	45 Minutes

5. Start brewing

Press the Brew button to begin the brew cycle. The Brew LED will illuminate and brewing will begin. The coffee filter basket gently spins and pauses throughout the brew cycle.

To cancel brewing, press Brew button once; the indicator light will go off and brew cycle will stop.

6. After brewing

When the brewing cycle has been completed, 3 beeps will sound and the Brew and selected strength LEDs will start flashing, signaling that the coffee is ready to be released into the carafe.

7. Release coffee into the carafe

Slide the coffee release lever to the right, to the Release position. Blue coffee release indicator light will illuminate and white indicator lights will go off. Coffee will stream into the carafe for approximately 2 minutes. The coffee filter basket will go through a final spin cycle while coffee is being filtered into the carafe. Once the coffee release cycle is finished, 5 beeps will sound, indicating that coffee is ready to be served.

NOTE: Removing the carafe before the release cycle is completed will cause the coffee to flow out onto the counter.



Never immerse base unit in water or other liquids. To clean base, simply wipe with a clean, damp cloth and dry before storing.

Fingerprints and other blemishes on the housing can be washed off with soap and water or a nonabrasive cleaning solution.

Maintenance

Any other servicing should be performed by an authorized service representative.

8. Slide lever back to the Lock position and enjoy your Cuisinart® Cold Brew Coffee!

CLEANING AND MAINTENANCE

Always turn coffeemaker off and remove the plug from the electrical outlet before cleaning.

1. Lift off the coffeemaker lid.
2. Use the handle to remove the water tank from the unit.
3. Remove the coffee filter basket from the water tank to discard ground coffee.
4. The water tank and coffee filter basket can be washed in warm, soapy water and rinsed thoroughly, or cleaned in the upper rack of the dishwasher.
NOTE: The coffee filter basket should be soaked regularly in warm, soapy water for 30 minutes to prevent oil buildup.
5. Dry all parts after use.
6. **Do not put any water in the unit once the water tank has been removed. Wipe the area under the water tank with a damp cloth.**
7. Remove the carafe from the base. Discard any remaining coffee.
8. Remove the carafe lid from the carafe filter by lightly pressing on both sides of the filter while pulling off the lid.
9. The carafe lid and filter can be washed in warm, soapy water and rinsed thoroughly, or cleaned in the upper rack of the dishwasher.

Do not use any scouring agents or harsh, abrasive cleansers on any part of the coffeemaker.

TROUBLESHOOTING GUIDE

Problem	Cause	Solution
Water is pouring out onto the counter	Coffee release lever is not in the lock position	<ul style="list-style-type: none"> • Slide coffee release lever to the Lock position • Always keep coffee release lever in the Lock position before and after release cycle
The unit will not work		
Coffeemaker lid is shaking during brew cycle	Coffee filter basket is not in place	<ul style="list-style-type: none"> • Press Brew button to pause the brew cycle • Remove coffeemaker lid • Make sure coffee basket filter twist-off lid is screwed on correctly • Push coffee filter basket down until clicked into the water tank • Replace coffeemaker lid and press the Brew button to continue the brew cycle
Coffee filter basket is filled with more water than usual after the release cycle has been completed	Coffee oils build up over time	<ul style="list-style-type: none"> • Soak coffee filter basket in warm, soapy water for 30 minutes • Soak coffee filter basket regularly to prevent oil buildup
	Coffee is too dark and oily	<ul style="list-style-type: none"> • When using a very dark, oily bean, coffee may not drain as efficiently as a regular roast or less oily bean
Coffee is weaker than usual	Coffee to water ratio is incorrect	<ul style="list-style-type: none"> • Adjust coffee-to-water ratio to taste • When using the MAX 16 scoops of coffee, reduce the amount of water
	Strength setting is incorrect	<ul style="list-style-type: none"> • Check your strength setting — selected strength indicator LED is illuminated • To change your strength setting, press the desired strength button
	Oil buildup in the coffee filter basket can prevent coffee from filtering properly	<ul style="list-style-type: none"> • Soak coffee filter basket in warm, soapy water for 30 minutes before running next brew cycle • Soak coffee filter basket regularly to prevent oil buildup • Avoid using a very dark, oily bean
The brew cycle has ended but no coffee is in the carafe.	Coffee release lever is in the lock position.	<ul style="list-style-type: none"> • Slide coffee release lever to right so it is in the release position. • The blue release indicator light will illuminate and coffee will begin to stream into the carafe.
The unit will not operate and the button indicator lights are flashing	The coffee filter basket may be jammed or not in the correct position	<ul style="list-style-type: none"> • Press the brew button once to cancel the cycle • Remove coffeemaker lid • Remove the coffee filter basket • Replace the coffee filter basket back into the water tank making sure it is securely in position • Replace the coffeemaker lid and restart the brew cycle

WARRANTY

LIMITED THREE-YEAR WARRANTY

(U.S. and Canada only)

We warrant that this Cuisinart product will be free of defects in materials or workmanship under normal home use for 3 years from the date of original purchase. This warranty covers manufacturer's defects including mechanical and electrical defects. It does not cover damage from consumer abuse, unauthorized repairs or modifications, theft, misuse, or damage due to transportation or environmental conditions. Products with removed or altered identification numbers will not be covered.

This warranty is not available to retailers or other commercial purchasers or owners. If your Cuisinart product should prove to be defective within the warranty period, we will repair it or replace it if necessary. For warranty purposes, please register your product online at www.cuisinart.ca to facilitate verification of the date of original purchase and keep your original receipt for the duration of the limited warranty. This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discolouration or other damage to external or internal surfaces that does not impair the functional utility of the product. This warranty also expressly excludes all incidental or consequential damages.

Your Cuisinart product has been manufactured to the strictest specifications and has been designed for use only in 120 volt outlets and only with authorized accessories and replacement parts. This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, as well as use with accessories, replacement parts or repair service other than those authorized by Cuisinart.

If the appliance should become defective within the warranty period, do not return the appliance to the store. Please contact our Customer Service Centre:

Toll-free phone number:

1-800-472-7606

Address:

Cuisinart Canada
100 Conair Parkway
Woodbridge, ON L4H 0L2

Email:

consumer_Canada@conair.com

Model:

DCB-10C

To facilitate the speed and accuracy of your return, please enclose:

- \$10.00 for shipping and handling of the product (cheque or money order)
- Return address and phone number
- Description of the product defect
- Product date code*/copy of original proof of purchase
- Any other information pertinent to the product's return

* Product date code can be found on the underside of the base of the product. The product date code is a 4 or 5 digit number. Example, 90630 would designate year, month & day (2009, June 30th).

Note: We recommend you use a traceable, insured delivery service for added protection. Cuisinart will not be held responsible for in-transit damage or for packages that are not delivered to us.

To order replacement parts or accessories, call our Customer Service Centre at 1-800-472-7606.

For more information, please visit our website at www.cuisinart.ca.

Cuisinart®



Coffeemakers



Blenders



Juicers



Cookware



Tools and
Gadgets

Cuisinart™ offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances and cookware, and Savor the Good Life®.

www.cuisinart.ca

Trademarks or service marks of third parties referred to herein are the trademarks or service marks of their respective owners.

©2017 Cuisinart Canada
100 Conair Parkway,
Woodbridge, ON L4H 0L2

Printed in China

17CC028675

IB-14805-CAN