

# Cuisinart<sup>®</sup> INSTRUCTION AND RECIPE BOOKLET



Cuisinart<sup>®</sup> Microwave Popcorn Maker

CTG-00-MPMC

# CONTENTS

|   |     |
|---|-----|
| Important Safeguards and Instructions . . . . . | 2-4 |
| Cleaning and Maintenance . . . . .              | 4   |
| Recipes . . . . .                               | 5-6 |
| Warranty . . . . .                              | 7   |

# IMPORTANT SAFEGUARDS

## SAVE AND READ THESE INSTRUCTIONS

Basic safety precautions should always be taken, including the following:

1. **READ ALL INSTRUCTIONS, including these important safeguards and the care and use instructions in this manual.**
2. **Do not use this bowl for other than its intended use.**
3. **The use of accessory attachments not recommended by Cuisinart may cause injuries.**
4. Do not use if the bowl has been damaged in any manner.
5. Allow bowl to cool down before handling or moving.
6. Do not touch hot surfaces. Always use handles.
7. Do not use this bowl or the lid on the stove top, under the broiler, in the freezer, or in the oven.
8. Extreme caution must be used when unloading popcorn.
9. Close supervision is necessary when this bowl is used by or near children.
10. Keep out of reach of children.
11. Do not clean using any abrasive materials.

12. Do not use this popcorn bowl without popcorn kernels and lid.
13. Bowl is dishwasher safe. Lid is hand-wash only.
14. Allow to cool before cleaning the bowl and lid.
15. Do not place on or near a hot gas or electric burner, or in a heated oven.

## **SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY**

### **PARTS**

1. Lid
2. Collapsible Popping Bowl

### **POPPING CHART GUIDE**

| <b>Corn Kernels</b>  | <b>Cook Time</b>     | <b>Yield</b>     |
|----------------------|----------------------|------------------|
| 2 Tablespoons (30 g) | 3 minutes            | 5 Cups (1.18 L)  |
| ¼ Cup (54 g)         | 3 minutes 45 seconds | 8 Cups (1.89 L)  |
| ⅓ Cup (67 g)         | 4 minutes            | 10 Cups (2.36 L) |

### **NOTE:**

1. Cook times are estimates. May take more or less time depending on the wattage of the microwave being used. All times are based on using “High” setting on the microwave.
2. Do not use the microwave popcorn function, as this function was designed for pre-packaged microwave popcorn bags.
3. Do not exceed 5 minutes’ popping time, as this might burn the popcorn and results in the discoloration of the inside surface of the bowl.

## **INSTRUCTIONS FOR POPPING CORN**

1. Fully extend the bowl with every use regardless of the batch size you are popping. Put recommended amount of kernels into the bowl. Do not add more kernels than the maximum amount recommended. Spread corn evenly over the bottom of the bowl.
2. Place plastic lid on popping bowl. Microwave based on quantity of kernels being popped.
3. Popcorn is now ready for serving. Sprinkle popcorn with salt or follow the enclosed recipes if desired.
4. For consecutive batches, wipe popping bowl with clean cloth prior to each new batch.
5. Place bowl on counter, hold handles and push down to collapse bowl for easy storage.

## **POPPING ADDITIONAL BATCHES OF POPCORN**

If you plan to pop multiple batches, transfer popcorn from popping bowl to another serving bowl. Follow steps 1 through 4.

## **CLEANING AND MAINTENANCE**

1. Clean the popcorn bowl after every use. Always allow bowl to cool before cleaning.
2. Popcorn bowl is dishwasher safe.
3. Lid is hand-wash only.
4. Do not clean using abrasive materials.

# RECIPES

## Cinnamon-Sugar Popcorn

*This classic combination of butter paired with cinnamon sugar makes a delicious popcorn treat!*

Makes about 10 cups (2.36 L)

- 1/3 cup (79 ml) popcorn kernels**
- 3 tablespoons (45 ml) unsalted butter**
- 2 tablespoons (30 ml) granulated sugar**
- 1/4 teaspoon (1 ml) ground cinnamon (add an extra pinch if you are a big cinnamon lover!)**  
**Pinch kosher salt**

1. Put the kernels into the popping bowl; cover with lid. Microwave for 4 minutes on High (Note: Some microwaves have different wattages, so this may take more or less time depending on the microwave being used).
2. While the corn is popping, melt the butter in a small skillet over medium-low heat. Remove from heat; reserve. Stir the sugar, cinnamon and salt together; reserve.
3. Once the popcorn is ready, remove lid, drizzle butter over the popped corn and then sprinkle with the cinnamon-sugar. Cover and toss to combine, or stir together with a heatproof spatula until fully coated. Serve immediately.

*Nutritional information per 1-cup (237 ml) serving:*

*Calories 69 (47% from fat) • carb. 8g • pro. 1g • fat 4g • sat. fat 2g  
chol. 9mg • sod. 14mg • calc. 2mg • fiber 1g*

## Parmesan Popcorn

*Parmesan gives this popcorn a great cheesy and tangy flavor.*

Makes about 10 cups (2.36 L)

- 1/3 cup (79 ml) popcorn kernels**
- 2 tablespoons (30 ml) extra virgin olive oil**
- 1/3 to 1/2 cup (79-118 ml) grated Parmesan**  
**Pinch kosher salt**

1. Put the kernels into the popping bowl; cover with lid. Microwave for 4 minutes on High (Note: Some microwaves have different wattages, so this may take more or less time depending on the microwave being used).
2. Once the popcorn is ready, remove the lid and drizzle the oil over the popped corn. Sprinkle with the Parmesan and salt. Cover and toss to combine, or stir together with a heatproof spatula until fully coated. Serve immediately.

*Nutritional information per 1-cup (237 ml) serving:*

*Calories 64 (53% from fat) • carb. 6g • pro. 2g • fat 4g • sat. fat 1g  
chol. 2mg • sod. 54mg • calc. 30mg • fiber 1g*

## Southwestern Popcorn

*All of your favourite Southwest flavours make for a delicious treat when paired with popcorn. Throw in some toasted pepitas for extra crunch!*

Makes about 10 cups (2.36 L)

- 1/3 cup (79 ml) popcorn kernels**
- 3 tablespoons (45 ml) grapeseed oil**
- 1 teaspoon (5 ml) chili powder**
- 1 teaspoon (5 ml) paprika**
- 1/2 teaspoon (2.5 ml) kosher salt**
- 1/4 teaspoon (1 ml) dried oregano**
- 1/4 teaspoon (1 ml) granulated garlic**
- 1/8 teaspoon (0.5 ml) cayenne pepper**

1. Put the kernels into the popping bowl; cover with lid. Microwave for 4 minutes on High (Note: Some microwaves have different wattages, so this may take more or less time depending on the microwave being used).
2. While the corn is popping, stir the spices and salt together; reserve. Once the popcorn is ready, remove the lid and drizzle the oil over the popped corn. Sprinkle with the combined spices and salt. Cover and toss to combine, or stir together with a heatproof spatula until fully coated. Serve immediately.

*Nutritional information per 1-cup (237 ml) serving:*

*Calories 59 (61% from fat) • carb. 5g • pro. 1g • fat 4g • sat. fat 0g  
chol. 0mg • sod. 109mg • calc. 2mg • fiber 1g*

# WARRANTY

## Limited Lifetime Warranty

Cuisinart® Tools & Gadgets are warranted to be free of defects in material and workmanship under normal home use from the date of original purchase throughout the original purchaser's lifetime. If your tool/gadget should prove to be defective within your lifetime, we will repair it (or, if we think it necessary, replace it) without charge to you, except for shipping and handling. To obtain warranty service, please call our Consumer Service Centre toll-free at 1-800-472-7606, or write to Consumer Service Centre, Cuisinart Canada, 100 Conair Parkway, Woodbridge, Ontario, L4H 0L2. To facilitate the speed and accuracy of your return, please also enclose \$4.00 for shipping and handling of the product. Be sure to include a return address, description of the product problem, phone number, and any other information pertinent to the product's return. Please pay by check or money order. Please note the party to whom the check or money order should be made payable to Conair Canada.

This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration or other damage to external or internal surfaces that does not impair the functional utility of the tool/gadget. This warranty also expressly excludes all incidental or consequential damages.

# Cuisinart®



Food  
Processors



Juicers



Coffeemakers



Cookware



Tools and  
Gadgets

Cuisinart® offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances, cookware, tools and gadgets.

**[www.cuisinart.ca](http://www.cuisinart.ca)**

©2019 Cuisinart Canada

100 Conair Parkway,  
Woodbridge, ON L4H 0L2

Consumer Call Centre E-mail:  
[Consumer\\_Canada@Conair.com](mailto:Consumer_Canada@Conair.com)

Printed in China  
19CC034517

Trademarks or service marks of third parties used herein are the trademarks or service marks of their respective owners.

IB-13534-CAN-A