

Cuisinart™

INSTRUCTION BOOKLET

Recipe
Booklet
Included



Breakfast Central™ Belgian Waffle/Omelet Maker

WAF-600C

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IB-9968A-CAN

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed:

1. **READ ALL INSTRUCTIONS.**
2. Do not touch hot surfaces; use handles. Always use oven mitts when handling hot material.
3. To protect against risk of electrical shock, do not immerse the Breakfast Central™ housing in water or any other liquid. If housing falls into liquid, unplug the cord from outlet immediately. **DO NOT reach into the liquid.**
4. To avoid possible accidental injury, close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance has malfunctioned or has been dropped or damaged in any way or is not operating properly. Return the appliance to the Customer Service Centre (see Warranty for details) for examination, repair or mechanical or electrical adjustment.
7. The use of attachments not recommended by Cuisinart may cause fire, electrical shock, or risk of injury.
8. Do not use outdoors or anywhere the cord or unit housing might come into contact with water while in use.
9. Do not let power cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.

11. Unplug the unit when finished baking waffles.
12. Always begin by plugging appliance into wall outlet. To disconnect, turn control to setting #1, then remove plug from wall outlet.
13. Extreme caution must be used when moving an appliance containing hot oil or other liquids.
14. **WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, REPAIR SHOULD BE DONE ONLY BY AUTHORIZED PERSONNEL. DO NOT REMOVE THE BASE PANEL. NO USER-SERVICEABLE PARTS ARE INSIDE.**

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

GROUNDING INSTRUCTIONS


For your protection, the Cuisinart™ Breakfast Central™ Belgian Waffle/Omelet Maker is supplied with a molded 3-prong grounding-type plug and should be used in combination with a properly connected grounding-type outlet as shown in the figure.

SPECIAL CORD SET INSTRUCTIONS

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord. Extension cords may be used if care is exercised in their use.

If an extension cord is used, the marked electrical rating of the exten-

sion cord should be at least as great as the electrical rating of the appliance, and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or animals, or tripped over. The extension cord should be a grounding 3-wire cord.



CONTENTS

Important Safeguards.....	2
Before First Use	3
Special Features	4
Instructions for Use.....	5
Tips.....	6
Recipes	7
Cleaning and Maintenance	15

BEFORE FIRST USE

1. Before using your Cuisinart™ Breakfast Central™ Belgian Waffle/Omelet Maker for the first time, remove any dust from shipping by wiping the plates with a damp cloth. Remove all protective paper and wrapping.
2. The first time you use your waffle/omelet maker, it may have a slight odour and may smoke a bit. This is normal and common to heating appliances.
3. **NOTE: This Cuisinart™ Breakfast Central™ Professional**


Belgian Waffle/Omelet Maker has been treated with a special nonstick coating. Before the first use, we suggest you season the waffle grids and omelet plates by brushing with cooking oil. Wipe with a paper towel or pastry brush.

IMPORTANT NOTICE!

TO FACILITATE OPENING AND CLOSING THE WAFFLE/OMELET MAKER, PLEASE FOLLOW THE INSTRUCTIONS BELOW.


TO OPEN:

Place thumb on top of lip of lower handle and index finger under lip of upper handle. Push open.



TO CLOSE:

Place thumb on top handle and fingers under bottom handle and pull together until shut.




NOTE: Please note that top and bottom grid covers may separate slightly during use. This is normal. Should this occur, do not close handles until unit beeps, indicating that baking cycle is completed. Then, rotate to open. To reduce grid separation and overflow during cooking, you may want to reduce the quantity of batter.

SPECIAL FEATURES

1. **Deep 1" (25 mm) Waffle Grids**
2. **Omelet/Pancake Compartment**
3. **Browning Control Knobs**
Adjustable for different batters and personal preference.
4. **On/Off Switch**
5. **Indicator Lights**

Two green LEDs: one for waffle side and one for omelet side will illuminate when unit is at the proper temperature and will re-illuminate when each side is done.



6. **Indicator Beeps** (not shown)
 - Six beeps indicate unit is ready to bake.
When the waffle/omelet maker is first plugged into electrical outlet and turned to the ON position, it will beep six times, indicating it has reached baking temperature.
 - Please note:** This will only occur for the first waffle/omelet of each baking session.
 - Three beeps indicate waffle/omelet is done.
7. **Measuring Cup**

INSTRUCTIONS FOR USE

TO MAKE ONE WAFFLE

1. Plug cord into 120V AC wall or outlet.
2. Press rocker switch to ON position.
3. Turn browning control knob to the desired setting for a waffle. We recommend setting #4 or preferred setting.
4. The waffle/omelet maker will now begin the preheating process. This should take approximately six minutes. When the waffle/omelet maker is ready for baking, the green indicator light located on each of the upper and lower grid covers will light, and the waffle/omelet maker will sound six beeps. (This is for first waffle/omelet of each baking session.)

- NOTE:** When baking two items at the same time, the waffle/omelet maker will beep 3 times to indicate when each waffle/omelet is ready. The green indicator lights located on the grid covers will also be illuminated.
5. Preheat your Cuisinart™ Breakfast Central™ Belgian Waffle/Omelet Maker on setting #4 or preferred setting (green indicator light located on grid cover will be illuminated when preheated).
 6. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism.

7. Using the waffle recipes provided, fill the measuring cup to the top of the cup. Pour batter evenly into the centre of the waffle grid. Use a heatproof spatula to spread the batter evenly over the grid.
8. Close top cover and rotate the waffle grid 180°.
9. The green Ready indicator light will turn off.
10. When the waffle is baked to the set darkness, the unit will beep three times and the green indicator light will illuminate.
11. Rotate waffle grid with the lit indicator light to the top position.
12. Raise top cover and remove the baked waffle.
13. Repeat if making additional waffles.
14. Packaged Belgian waffle mixes found in most supermarkets, may also be used with this unit.

TO MAKE ONE OMELET

1. Raise top cover of omelet side and pour egg mixture (2 eggs) evenly on the omelet plate. Bake at setting #4 or preferred setting.
2. **Close top lid over and let mixture stand for 20 seconds. The green indicator light will flash for 20 seconds, then turn solid. After flash has stopped, rotate the omelet side 180°.**
3. When the omelet is baked to the set doneness, the unit will beep three times and a green indicator light located on the omelet cover will light.
4. Rotate the compartment with the lit indicator light to the top position.

5. Raise the top cover and remove the baked omelet.
6. If making additional omelets, repeat the instructions above.
7. When finished, turn unit switch to the OFF position and allow the unit to cool before cleaning.

Note: Omelet side can also be used to make one extra-large pancake, sunnyside fried eggs, or to toast an English muffin facedown.

Note: One waffle and one omelet can be baked at the same time. Please follow above instructions.

TIPS FOR MAKING PERFECT BELGIAN WAFFLES

We recommend setting #4 when using commercial pancake/waffle mixes.

We recommend setting #4 for Belgian waffle recipes.

If you prefer crisper, darker Belgian waffles, increase the browning setting.

For evenly filled waffles, pour the batter into the centre of the lower grid and spread out evenly to the edges. The entire lower grid should be filled.

For best results, we recommend filling the supplied cup to the top so it will fill the lower grid with the correct amount of batter.

For added convenience while baking waffles, rest measuring scoop with handle hanging on outside of bowl and scoop on inside of bowl until the next baking cycle.

To measure flour, stir the flour first to aerate it, since it settles when it sits. Then spoon it into a measuring cup, leveling off the top with the back of a knife – do not pack down into measuring cup. These quick steps will help you avoid heavy waffles. Belgian waffles taste best when made to order, but baked Belgian waffles may be kept warm in a 200°F (95°C) oven. Place in a baking pan or wrap in foil while in the oven. Waffles wrapped in foil may lose their crispness.

Baked waffles may be frozen. Allow to cool completely, and then place in a plastic food storage bag. Use waxed paper to keep waffles separated. Reheat in an oven, toaster or toaster oven when ready to use.

If waffles tend to stick to waffle grids, add slightly more oil or butter to the batter.

SUGGESTED TOPPINGS

Maple syrup, fruit syrups

Warm fruit compote, fruit sauce

Fresh berries, chopped fruit, chopped nuts

Powdered sugar

Whipped cream, ice cream, sorbet

Chocolate sauce

Fruited yogurt

RECIPES

For Use with Omelet/ Pancake Compartment

Frittata

Makes one frittata

- 2 large eggs, mixed well**
- 1/2 ounce (15 g) of shredded whole milk mozzarella**
- 2 ounces (60 g) of cubed cooked potatoes**
- pinch of salt and pepper**

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting (green indicator light will be illuminated when preheated).

Mix all ingredients together and then pour the egg mixture into the Breakfast Central™ omelet side. **Close top lid over and let mixture stand for 20 seconds. The green indicator light will flash for 20 seconds, then turn solid. After flash has stopped, rotate the omelet side 180°.** This will allow the egg mixture to set.

Cook on setting #4 or desired setting. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism. When the frittata is baked to the set doneness, the unit will beep three times and the green light located on the cover of the omelet side will illuminate.

Nutritional information per frittata:
Calories 200 (50% from fat) • carb. 11g
 • pro. 15g • fat 12g • sat. fat 4g
 • chol. 382mg • sod. 260mg
 • calc. 197mg • fiber .67g

Ham & Cheese Omelet

Makes one omelet

- 2 large eggs, mixed well**
- 2 ounces (60 g) of ham**
- 1 ounce (30 g) of mozzarella dash of salt and pepper**

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting (green indicator light will be illuminated when preheated).

Mix all ingredients together and then pour the egg mixture into the Breakfast Central™ omelet side. **Close top lid over and let mixture stand for 20 seconds. The green indicator light will flash for 20 seconds, then turn solid. After flash has stopped, rotate the omelet side 180°.** This will allow the egg mixture to set.

Cook on setting #6 or desired setting. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism. When the omelet is baked to the set doneness, the unit will beep three times and the green light located on the cover of the omelet side will illuminate.

Nutritional information per omelet:
Calories 247 (66% from fat) • carb. 2g
 • pro. 18g • fat 18g • sat. fat 10g
 • chol. 399mg • sod. 420mg
 • calc. 197mg • fiber 0g

Pancakes

Makes about 12 servings

- 1 cup (250 ml) milk
- 1 cup (250 ml) pancake mix (you can use any store bought pancake mix)
- 1 egg or homemade batter)
- 1 tablespoon (15 ml) oil

Preheat your Cuisinart™ Breakfast Central™ on setting #3 or preferred setting (green indicator light will be illuminated when preheated).

Mix all ingredients together in a 4-cup (1 L) glass measuring bowl. Pour 1 cup (250 ml) into the Breakfast Central™ omelet side. **Close top lid over and let mixture stand for 20 seconds. The green indicator light will flash for 20 seconds, then turn solid. After flash has stopped, rotate the omelet side 180°.** This will allow the mixture to set.

Cook on setting #3 or desired setting until unit beeps. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism. When the pancake is baked to the set darkness, the unit will beep three times and the green light located on the cover of the omelet side will illuminate.

Nutritional information per pancake:
Calories 75 (3% from fat) • carb. 8g
• pro 4g • fat 2g • sat. fat .5g
• chol. 19mg • sod. 169mg
• calc. 82mg • fiber 3g

Cornmeal Pancakes

Makes 4 to 5 servings

- 1¼ cups (300 ml) buttermilk
- 1 egg
- 1½ cup (300 ml) cornmeal
- ½ teaspoon (2 ml) baking soda
- ½ teaspoon (2 ml) salt

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting (green indicator light will be illuminated when preheated).

Mix all ingredients together in a 4-cup (1 L) glass measuring bowl. Pour 4 ounces or ½ cup (125 ml) into the Breakfast Express omelet side. **Close top lid over and let mixture stand for 20 seconds. The green indicator light will flash for 20 seconds, then turn solid. After flash has stopped, rotate the omelet side 180°.** This will allow the mixture to set.

Cook on setting #4 or desired setting until golden brown. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism. When the pancake is baked to the set darkness, the unit will beep three times and the green light located on the cover of the omelet side will illuminate.

Nutritional information per pancake:
Calories 540 (1.4% from fat) • carb. 100g
• pro 16g • fat 4g • sat. fat 2g
• chol. 56mg • sod. 1112mg
• calc. 197mg • fiber 1g

Breakfast French Toast with Ham & Cheese

Makes one sandwich

- ¼ cup (50 ml) of milk (can be whole, skim or 2%)
- 2 eggs
- pinch of cinnamon
- 2 slices of bread
- 2 slices of ham
- 1 slice of American cheese

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting (green indicator light will be illuminated when preheated).

Whisk milk, eggs and cinnamon together to thoroughly mix. Dip one side of bread into egg mixture. Place coated side of bread onto omelet plate of Breakfast Central™. Layer one slice of ham, one slice of cheese, and another slice of ham on top of coated bread. Dip second piece of bread into egg mixture and place coated side over the ham and cheese, facing up.

Close lid and rotate unit 180° to the right. For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism. When the sandwich is baked to the set darkness, the unit will beep three times and the green light located on the cover of the omelet side will illuminate.

Nutritional information per sandwich:
Calories 405 (46% from fat) • carb. 20g
• pro. 3g • fat 21g • sat. fat 8g
• chol. 401mg • sod. 860mg
• calc. 325mg • fiber 8g

Quick English Muffins

Makes five muffins

- 1 pizza dough (from supermarket)
- yellow cornmeal for dusting

Preheat your Cuisinart™ Breakfast Central™ on setting #5 or preferred setting (green indicator light will be illuminated when preheated).

Divide pizza dough into 5 pieces. Roll dough into a ball, then roll to lightly coat with yellow cornmeal on both sides. Place one dough circle on omelet plate. Close lid and rotate unit 180° to the right.

Bake on setting #4 or desired setting for 8 minutes. **You must time this; ignore ready beeps.**

Nutritional information per muffin:
Calories 85 (10% from fat) • carb. 8g
• pro. 5g • fat 6g • sat. fat .7g
• chol. 0mg • sod. 500mg
• calc. 3mg • fiber 3g

Fried Eggs

non-stick cooking spray
large eggs

2

Preheat your Cuisinart™ Breakfast Central™ on setting #2 or preferred setting (green indicator light will be illuminated when preheated).

Spray omelet plates with nonstick cooking spray. Crack eggs into omelet side of Breakfast Central™. Close lid and cook on setting #2 or desired setting.

Do not rotate unit. Cook for two minutes or until desired doneness; ignore the ready beeps.

Nutritional information per serving (2 eggs):
Calories 129 (63% from fat) • carb. 7g
• pro. 11g • fat 9g • sat. fat 3g
• chol. 372mg • sod. 125mg
• calc. 47mg • fiber 0g

Cornbread

Makes 6 servings

- 1¼ cups (300 ml) all-purpose flour
- ¾ cup (175 ml) cornmeal
- ¼ cup (50 ml) sugar
- 2 teaspoons (10 ml) baking powder
- ½ teaspoon (2 ml) salt
- 1 cup (250 ml) milk
- 1 egg, beaten
- ¼ cup (50 ml) vegetable oil

Preheat your Cuisinart™ Breakfast Central™ on setting #5 or preferred setting (green indicator light will be illuminated when preheated).

In a large bowl, combine flour, cornmeal, sugar, baking powder and salt. Stir in milk, egg and oil until just moistened. Pour 1½ cups (375 ml) of cornbread mixture into the Breakfast Central™ omelet side.

Close lid and let stand 30 seconds before turning. This will allow the mixture to set. Rotate unit 180° to the right. For best results, do not open waffle/omelet maker during cooking process.

Note: You can also use Betty Crocker Cornbread mix. Prepare as directed and pour onto omelet side of Breakfast Central™. Do not follow package cook times for this recipe as the Breakfast Central™ will have a much shorter cooking time.

Nutritional information per serving:
Calories 616 (9% from fat) • carb. 61g
• pro. 9g • fat 40g • sat. fat 3g • chol. 6mg
• sod. 330mg • calc. 62mg • fiber 5g

RECIPES For Use with Waffle Compartment

Good Night Waffles

Most of the mixing for these waffles is done the night before. In the morning, just mix in the eggs, vanilla extract and baking soda while the waffle maker is heating. Leftover batter may be covered and kept in the refrigerator for up to 3 days. Heat your waffle maker in the morning, stir the batter and have a freshly baked waffle for breakfast.

Makes 6 waffles

- ½ cup (125 ml) lukewarm (105°F [41°C]) water
- 1 tablespoon (15 ml) granulated sugar
- 2¼ teaspoons (17 ml) active dry yeast (1 yeast packet)
- 2 cups (500 ml) whole milk, warmed (about 105°F [41°C])
- ½ cup (125 ml) unsalted butter, melted and cooled
- 1 teaspoon (5 ml) salt
- 2 cups (500 ml) all-purpose flour
- 2 large eggs, lightly beaten
- 2 teaspoons (10 ml) pure vanilla extract
- ¼ teaspoon (1 ml) baking soda

The night before, or at least 8 hours before baking, combine the warm water, granulated sugar and yeast. Let stand 10 minutes, until foamy. Stir in the warm milk, melted butter and salt. Beat in the flour until smooth; (this may be done using a hand mixer on low speed).

Wrap bowl tightly with plastic wrap and let stand overnight (or for 8 hours) on the countertop; do not refrigerate.

When ready to bake, preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting* (green indicator light will be illuminated when preheated).

For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism.

While the waffle/omelet maker is heating, stir the eggs, vanilla extract and baking soda into the batter. Use measuring scoop to measure out batter. Pour into waffle grids. Use a heat-proof spatula to spread the batter evenly over the grids. Close cover and rotate 180° to the right. Bake in the hot waffle maker until beeper sounds. Rotate 180° to the left. Remove waffle and repeat with remaining batter. Waffles may be kept warm in a low (200°F [95°C]) oven. Place waffles arranged on a cookie sheet on a rack in the oven. Serve with sliced fresh fruit, jam, powdered sugar, a warm fruit syrup, or whipped cream.

* We recommend using setting #4 to achieve a golden brown baked Belgian waffle. Adjust the browning control if you prefer lighter or darker waffles.

Nutritional information per waffle:
Calories 373 (49% from fat) • carb. 38g
• pro. 10g • fat 20g • sat. fat 12g
• chol. 123mg • sod. 501mg
• calc. 117mg • fiber 1g

Classic Belgian Waffles

Classic Belgian waffles have a crispy outside and are soft and moist on the inside. They are often served as part of a celebration – even to celebrate something as simple as a beautiful day. Try these waffles with your favourite syrup or a topping such as sliced fresh strawberries and freshly whipped cream.

Makes 10 waffles

- 1½ cups (375 ml) water, divided
- 2¼ teaspoons (12ml) active dry yeast (one packet)
- ⅓ cup (75 ml) sugar
- 3 cups (750 ml) sifted flour
- ¼ teaspoon (1 ml) salt
- 3 large eggs, separated + 1 egg white
- 1½ cups (375 ml) whole milk
- 8 tablespoons (120 ml) unsalted butter - melted and cooled
- 2 teaspoons (10 ml) vegetable oil
- 2 teaspoons (10 ml) pure vanilla extract

Heat ½ of the water to lukewarm, 105°-110°F (41°-43°C). Dissolve the yeast in the water with a pinch of the sugar from the recipe; let stand 5 to 10 minutes, until the mixture begins to foam.

Put the flour and salt into a large bowl; stir to blend and reserve. Add the egg yolks, one of the egg whites, and remaining sugar to the yeast mixture; stir to blend. Add the remaining water, milk, melted butter, oil, and vanilla; stir until the mixture is smooth. Stir the liquid mixture into the flour mixture and beat until the mixture is smooth.

Beat the egg whites until stiff peaks form. Fold the egg whites gently into the batter. Let the batter stand for 1 hour, stirring every 15 minutes.

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting* (green indicator light will be illuminated when preheated).

For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism.

Use the measuring scoop to measure the batter and pour into the preheated waffle iron. Use a heatproof spatula to spread the batter evenly over the grids. Close lid and rotate waffle maker 180° to the right. Bake the waffles in the waffle iron until beeper indicates that the waffle is done. Rotate waffle maker 180° to the left. Remove waffle and repeat until all batter is used. Waffles may be kept warm in a low (200°F [95°C]) oven. Place waffles arranged on a cookie sheet on a rack in the warm oven. Serve with whipped cream, fruit, jam, powdered sugar, or a warm fruit syrup.

*We recommend using setting #4 to achieve a golden brown baked Belgian waffle. Adjust the browning control if you prefer lighter or darker waffles.

Nutritional information per waffle:

- Calories 300 (40% from fat)
- carb. 37g • pro. 8g • fat 13g
- sat. fat 7g • chol. 94mg • sod. 104mg
- calc. 61mg • fiber 1g

Gingerbread Belgian Waffles

These waffles have the flavour of just-baked gingerbread, and are delicious served with fresh fruit or caramelized apples and pears.

Makes 6 waffles

- ½ cup (125 ml) warm water
- 1 teaspoon (5 ml) granulated sugar
- 2¼ teaspoons (11 ml) active dry yeast (1 packet)
- 1½ cups (375 ml) all-purpose flour
- 1 cup (250 ml) graham cracker crumbs
- ¼ cup (50 ml) granulated sugar
- ¼ teaspoon (1 ml) salt
- 1 teaspoon (5 ml) ground ginger
- ½ teaspoon (2 ml) finely chopped lemon zest
- 2 cups (500 ml) warm milk (about 105°F [41°C])
- 3 large eggs, separated
- ½ cup (125 ml) unsalted butter, melted and cooled
- 1 teaspoon (5 ml) pure vanilla extract

Measure water into a large bowl. Add 1 teaspoon (5 ml) granulated sugar and yeast; stir to dissolve. Let stand 10 minutes. In a separate bowl, combine the flour, graham cracker crumbs, ¼ cup (50 ml) sugar, salt, ginger, and lemon zest; stir to combine. Add the milk, egg yolks, melted cooled butter, and vanilla to the yeast mixture. Stir until smooth. Add the dry ingredients and beat until smooth, using a hand mixer on low speed. Cover with waxed paper

and let stand to rise in a warm, draft-free place for 30 minutes.

Beat the egg whites until stiff, but not dry. Gently fold into the batter.

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting* (green indicator light will be illuminated when preheated).

For best results, do not open waffle/omelet maker during cooking process. Doing so will offset the timing mechanism.

Use the measuring scoop to measure out batter, spreading evenly into waffle grids. Close lid and rotate 180° to the right and bake in the hot waffle maker until beeper sounds. Rotate waffle side 180° to the left. Remove waffle and repeat with remaining batter. Waffles may be kept warm in a low (200°F [95°C]) oven. Place waffles arranged on a cookie sheet on a rack in the warm oven. Serve with lemon curd, fruit, jam, powdered sugar, a warm fruit syrup, or whipped cream.

* We recommend using setting #4 to achieve a golden brown baked Belgian waffle. Adjust the browning control if you prefer lighter or darker waffles.

- Nutritional information per waffle:
Calories 458 (44% from fat) • carb. 23g
• pro. 11g • fat 23g • sat. fat 12g
• chol. 159mg • sod. 279mg
calc. 120mg • fiber 1g

Pumpkin Nut Belgian Waffles

These waffles taste like freshly baked pumpkin muffins and are delicious served with warm maple syrup.

Makes 6 waffles

- 1½ cups (375 ml) all-purpose flour
- 1 ounce (30 g) finely chopped walnuts or pecans (best if toasted first)
- 1 tablespoon (15 ml) cornstarch
- 1 tablespoon (15 ml) baking powder
- 1 teaspoon (5 ml) salt
- 1 teaspoon (5 ml) ground cinnamon
- ½ teaspoon (2 ml) ground ginger
- ¼ teaspoon (1 ml) freshly ground nutmeg
- ¾ cup (175 ml) pumpkin purée (canned solid pack pumpkin)
- 2 large eggs, separated
- 1 cup (50 ml) whole milk
- ¼ cup (50 ml) real maple syrup (do not use pancake syrup)
- 3 tablespoons (45 ml) unsalted butter, melted
- 1 teaspoon (5 ml) pure vanilla extract
- 3 large egg whites

In a large bowl, combine the flour, chopped nuts, cornstarch, baking powder, salt, cinnamon, ginger, and nutmeg. Stir to blend and reserve.

In a second bowl, combine the pumpkin purée, egg yolks, milk, maple syrup, melted butter, and vanilla extract; stir until smooth. Add the liquid ingredients to the dry ingredients and stir to blend until smooth, using a whisk.

In a clean, dry bowl, beat the egg whites until stiff peaks form. Gently fold the beaten egg whites into the batter.

Preheat your Cuisinart™ Breakfast Central™ on setting #4 or preferred setting* (green indicator light will be illuminated when preheated).

For best results, do not open waffle maker during cooking process. Doing so will offset the timing mechanism.

Use measuring scoop to measure out batter. Pour into waffle grids. Use a heat-proof spatula to spread the batter evenly over the grids. Close cover and rotate 180° to the right. Bake in the hot waffle maker until beeper sounds. Rotate 180° to the left. Remove waffle and repeat with remaining batter. Waffles may be kept warm in a low (200°F [95°C]) oven. Place waffles arranged on a cookie sheet on a rack in the oven. Serve with warm maple syrup, powdered sugar, or whipped cream.

*We recommend using setting #4 to achieve a golden brown baked Belgian waffle. Adjust the browning control if you prefer lighter or darker waffles.

Nutritional information per waffle:
Calories 303 (35% from fat) • carb. 40g
• pro. 10g • fat 12g • sat. fat 5g
• chol. 92mg • sod. 579mg •
calc. 94mg • fiber 2g

CLEANING AND MAINTENANCE

Once you have finished baking, switch rocker switch to the OFF position; remove plug from electrical outlet. Leave top lid open and allow grids/plates to cool before cleaning.

Never take your Breakfast Central™ apart for cleaning. Simply brush crumbs from grooves and absorb any excess cooking oil by wiping with a dry cloth or paper towel. You may clean the grids/plates by wiping with a damp cloth to prevent staining and sticking from batter or oil buildup.

Be certain that grids/plates have cooled completely before cleaning. If batter adheres to grids/plates, simply pour a little cooking oil onto the baked batter and let stand approximately five minutes, allowing batter to soften for easy removal.


To clean exterior, wipe with a soft dry cloth. Never use an abrasive cleanser or harsh pad. **NEVER IMMERS** CORD, PLUG OR UNIT IN WATER OR OTHER LIQUIDS.

Maintenance: Any other servicing should be performed by an authorized service representative.

IMPORTANT NOTICE!

After unit is preheated, season waffle grids and omelet plates with cooking spray or brush with a flavourless oil to thoroughly coat all surfaces.

It is important that you preheat the Breakfast Central™ **before** seasoning with cooking spray or oil.



NOTE

When making omelets, frittatas, pancakes and corn bread, close top lid and let mixture stand for 30 seconds before rotating the omelet side 180°.

WARRANTY 3-YEAR LIMITED WARRANTY

We warrant that this Cuisinart product will be free of defects in material or workmanship under normal home use for 3 years from the date of original purchase.

This warranty covers manufacturer's defects including mechanical and electrical defects. It does not cover damage from consumer abuse, unauthorized repairs or modifications, theft, misuse, or damage due to transportation or environmental conditions. Products with removed or altered identification numbers will not be covered.

This warranty is not available to retailers or other commercial purchasers or owners.

If your Cuisinart product should prove to be defective within the warranty period, we will repair it or replace it if necessary.

For warranty purposes, please register your product online at www.cuisinart.ca to facilitate verification of the date of original purchase or keep your original receipt for the duration of the limited warranty.

This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discolouration or other damage to external or internal surfaces that does not impair the functional utility of the tool/gadget. This warranty also expressly excludes all incidental or consequential damages.

If the appliance should become defective within the warranty period, **do not return the appliance to the store.** Please contact our Customer Service Centre:

Toll-free phone number:
1-800-472-7606

Address:

Cuisinart Canada
100 Conair Parkway
Woodbridge, Ont. L4H 0L2

Email:
consumer_Canada@conair.com

Model:
WAF-600C

To facilitate the speed and accuracy of your return, please enclose:

- \$10.00 for shipping and handling of the product (cheque or money order)
- Return address and phone number
- Description of the product defect
- Product date code*/copy of original proof of purchase
- Any other information pertinent to the product's return

* Product date code can be found on the underside of the base of the product. The product date code is a 4 or 5 digit number. Example, 90630 would designate year, month & day (2009, June 30th).

NOTE: We recommend you use a traceable, insured delivery service for added protection. Cuisinart will not be held responsible for in-transit damage or for packages that are not delivered to us.

To order replacement parts or accessories, call our Customer Service Centre at 1-800-472-7606.

For more information, please visit our website at www.cuisinart.ca

Cuisinart®

SAVOR THE GOOD LIFE®



Coffeemakers
Cafetières



Food Processors
Robots de
cuisine



Toasters
Grille-pain



Blenders
Mélangeurs



Ice Cream
Makers
Sorbetières

Cuisinart® offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances and cookware, and Savor the Good Life®.

Cuisinart^{MD} offre une vaste gamme de produits de grande qualité qui facilitent la vie dans la cuisine comme jamais auparavant. Essayez nos autres appareils de comptoir et ustensiles de cuisson et Savor the Good Life®.

www.cuisinart.ca

Any trademarks or service marks of third parties used herein are the trademarks or service marks of their respective owners.

Toutes les autres marques de commerce ou de service utilisées dans le présent document appartiennent à leurs propriétaires respectifs.

©2011 Cuisinart Canada
100 Conair Parkway
Woodbridge, ON L4H 0L2
Consumer Call Centre E-mail:/
Centre d'appel des consommateurs
Consumer_Canada@Conair.com
1-800-472-7606
Printed in China/ Imprimé en Chine
11CC122433