

# Cuisinart™

## INSTRUCTION BOOKLET



**Classic Waffle Maker**

**WMR-CAC**

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

## TABLE OF CONTENTS

Important Safeguards .....	2
Instructions for Use.....	3
Special Features.....	3
Tips and Toppings .....	4
Recipes.....	4
Cleaning and Maintenance .....	7
Storage.....	7
Warranty.....	7

## IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed, including the following:

1. **READ ALL INSTRUCTIONS.**
2. **Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning appliance.**
3. Do not touch hot surfaces. Use handles and knobs.
4. To protect against fire, electrical shock, and injury to persons, **DO NOT IMMERSE CORD, PLUG, OR UNIT** in water or other liquids.
5. Close supervision is necessary when any appliance is used by or near children.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
7. The use of accessory attachments not recommended by Cuisinart may result in fire, electrical shock, or injury to persons.
8. Do not use outdoors.
9. Do not let power cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Unplug the unit when finished baking waffles.
12. Do not use appliance for other than intended use.

13. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn control to setting #1, then remove plug from the outlet.
14. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
15. **WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, REPAIR SHOULD BE DONE ONLY BY AUTHORIZED PERSONNEL. NO USER SERVICEABLE PARTS ARE INSIDE.**

## SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

### SPECIAL CORD SET INSTRUCTIONS

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

Longer extension cords are available and may be used if care is exercised in their use.

If a long extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or animals, or tripped over.

### NOTICE:

This appliance is of the grounded type; the extension cord should be grounded type 3-wire cord. If the plug does not fit, contact a qualified electrician, do not modify the plug in any way.

**WARNING:** Improper use of the grounding can result in risk of electric shock.


## INSTRUCTIONS FOR USE

1. Before using your Cuisinart™ Classic Waffle Maker for the first time, remove any dust from shipping by wiping the plates with a damp cloth. Remove all protective paper and wrapping.
2. Preheat the waffle maker. Close grids and plug cord into a 120V AC wall outlet. The red light will go on to signal power. Allow the waffle maker to preheat. The green indicator light will go on when it is ready to use.

**Note:** The first time you use your waffle maker, it may have a slight odour and may smoke a bit. This is normal, and common to appliances with a nonstick surface.

3. Pour batter when green indicator light goes on. Pour batter onto the center of the lower waffle grid. Use a heat-proof plastic spatula to spread batter evenly over the grids. Close the lid.
4. The green light will go off and the red light will once again illuminate. It may take several seconds for the red light to come on. This is normal.
5. Once the waffles are ready to eat, the green light will again come on.
6. Baking time is determined by browning level. Choose a setting on the browning control dial. We recommend using setting #3 for golden brown waffles.
7. Once the waffle is ready, remove it by gently loosening the edges with a heat-proof plastic spatula. Never use metal utensils, as they may damage the nonstick coating.
8. Always disconnect the plug from the wall outlet once baking is completed.

## SPECIAL FEATURES



1. **Browning Control Adjustment**  
- five settings to customize waffle maker from light to deep golden brown
2. **Indicator Lights**  
- signal when waffle maker is ready to bake  
- signal when waffles are ready to eat
3. **Weighted Lid**  
- lid will not rise as waffles bake
4. **Rubber Feet**  
- will not mark countertop  
- keep unit steady
5. **Brushed Stainless Steel Covers**
6. **Cord Storage**  
- cord wraps under bottom for easy storage
7. **BPA-Free (not shown)**  
- All parts that come in contact with food are BPA-Free

**Note:** The Cuisinart™ Classic Waffle Maker has been treated with a special nonstick coating. Before the first use, we suggest you season the grids with cooking spray or flavourless vegetable oil. If using oil, apply oil with a paper towel or pastry brush. You may find it helpful to repeat this process before each use of the waffle maker.

## TIPS TO MAKE PERFECT WAFFLES

We recommend setting #3 for golden brown waffles.

If you prefer crisper, darker waffles, increase the browning control to setting #4 or #5.

For evenly filled waffles, pour the batter onto the center of the lower grid and close the cover.

We recommend using ½ cup (125 ml) batter per waffle for evenly filled waffles.

Waffles are best when made to order, but baked waffles may be kept warm in a 200°F (95°C) oven. Place in a baking pan or wrap in foil while in the oven. Waffles wrapped in foil may lose their crispiness.

Baked waffles may be frozen. Allow to cool completely, then place in plastic food storage bag. Use waxed paper to keep waffles separated. Reheat in a toaster or toaster oven when ready to use.

## SUGGESTED TOPPINGS

Maple syrup, fruit syrups

Warm fruit compote, fruit sauce

Fresh berries, chopped fruit, chopped nuts

Powdered sugar

Whipped cream, ice cream, sorbet

Chocolate sauce

Fruited yogurt

## RECIPES

### BASIC WAFFLES

You can't beat the taste of homemade waffles. Freeze the extras to use when time is scarce.

Makes eight 6½ inch (1.25 cm) round waffles

- 2 cups (500 ml) all-purpose flour
- 2 tablespoons (30 ml) sugar
- 1 tablespoon (15 ml) baking powder
- ½ teaspoon (2 ml) salt
- 1¾ cups (425 ml) reduced fat milk
- 6 tablespoons (90 ml) vegetable oil
- 2 large eggs

Place ingredients in a large mixing bowl and combine until well blended and smooth. Let batter sit 5 minutes before using. Preheat your Cuisinart™ Classic Waffle Maker on setting #3 \*(green indicator light will be illuminated when preheated).

Pour ½ cup (125 ml) batter onto the center of the lower grid; spread evenly using a heat-proof spatula. Close cover of waffle maker. Indicator light will turn red. When light turns green again, waffle is ready. Open cover and carefully remove baked waffle. Repeat with remaining batter. For best results, serve immediately. However, you may keep waffles warm in a 200°F (95°C) oven until ready to serve.

\* We recommend using setting #3 to achieve a golden brown baked waffle. Adjust the browning control if you prefer lighter or darker waffles.

*Nutritional information per waffle:*

Calories 262 (44% from fat) • carb. 30g • pro. 7g  
• fat 13g • sat. fat 2g • chol. 57mg • sod. 372mg  
• calc. 177mg • fiber 1g

For Mini-Chip Waffles:

Add ½ cup (125 ml) mini chocolate morsels to the batter before baking.

### CORNMEAL WAFFLES

These waffles taste like cornbread. Drizzle with butter and serve with soup, chili or stew. Also good for brunch or a late night snack served with syrup or cheese sauce.

Makes eight 6½ inch (1.25 cm) round waffles

- 1¼ cups (300 ml) all-purpose flour
- ¾ cup (175 ml) yellow cornmeal
- 2 tablespoons (30 ml) sugar
- 1 tablespoon (15 ml) baking powder
- ½ teaspoon (2 ml) salt
- 1¾ cups (425 ml) reduced fat milk
- 6 tablespoons (90 ml) vegetable oil
- 2 large eggs

Place ingredients in a large mixing bowl and combine until well blended and smooth. Let batter sit 5 minutes before using. Preheat your Cuisinart™ Classic Waffle Maker on setting #3 \*(green indicator light will be illuminated when preheated).

Pour ½ cup (125 ml) batter onto the center of the lower grid; spread evenly using a heat-proof spatula. Close cover of waffle maker. Indicator light will turn red. When light turns green again, waffle is ready. Open cover and carefully remove baked waffle. Repeat with remaining batter. For best results, serve immediately. However, you may keep waffles warm in a 200°F (95°C) oven until ready to serve.

\* We recommend using setting #3 to achieve a golden brown baked waffle. Adjust the browning control if you prefer lighter or darker waffles.

*Nutritional information per waffle:*

Calories 264 (43% from fat) • carb. 32g • pro. 6g  
• fat 13g • sat. fat 2g • chol. 57mg • sod. 372mg  
• calc. 173mg • fiber 1g

### NUTTY WHOLE WHEAT WAFFLES

Wholesome wheat flavour combined with crunchy pecans makes a delicious breakfast, brunch or snack. Top with warm fruit compote or syrup.

Makes eight 6½ inch (1.25 cm) round waffles

- 1½ cups (375 ml) all-purpose flour
- ½ cup (125 ml) whole wheat flour
- 2 tablespoons (30 ml) sugar
- 1 tablespoon (15 ml) baking powder
- ½ teaspoon (2 ml) salt
- 2 cups (500 ml) reduced fat milk
- 6 tablespoons (90 ml) vegetable oil
- 2 large eggs
- ½ cup (125 ml) finely chopped pecans, walnuts, almonds, or hazelnuts

Place ingredients in a large mixing bowl and combine until well blended and smooth. Let batter sit 5 minutes before using. Preheat your Cuisinart™ Classic Waffle Maker on setting #3 \*(green indicator light will be illuminated when preheated).

Pour ½ cup (125 ml) batter onto the center of the lower grid; spread evenly using a heat-proof spatula. Close cover of waffle maker. Indicator light will turn red. When light turns green again, waffle is ready. Open cover and carefully remove baked waffle. Repeat with remaining batter. For best results, serve immediately. However, you may keep waffles warm in a 200°F (95°C) oven until ready to serve.

\* We recommend using setting #3 to achieve a golden brown baked waffle. Adjust the browning control if you prefer lighter or darker waffles.

*Nutritional information per waffle:*

Calories 263 (44% from fat) • carb. 30g • pro. 7g  
• fat 13g • sat. fat 2g • chol. 58mg • sod. 376mg  
• calc. 187mg • fiber 1g

## FRUITY WAFFLES

Puréed fruit adds lightness and delicate flavour to baked waffles.

Makes eight 6½ inch (1.25 cm) round waffles

- 2 cups (500 ml) all-purpose flour
- 2 tablespoons (30 ml) sugar
- 1 tablespoon (15 ml) baking powder
- ½ teaspoon (2 ml) salt
- 1¼ cups (425 ml) reduced fat milk
- 6 tablespoons (90 ml) vegetable oil
- 2 large eggs
- ½ cup (125 ml) puréed fruit\* or applesauce (use fresh or frozen)

Place ingredients in a large mixing bowl and combine until well blended and smooth. Let batter sit 5 minutes before using. Preheat your Cuisinart™ Classic Waffle Maker on setting #3 \*(green indicator light will be illuminated when preheated).

Pour a scant ½ cup (125 ml) batter onto the center of the lower grid; spread evenly using a heat-proof spatula. Close cover of waffle maker. Indicator light will turn red. When light turns green again, waffle is ready. Open cover and carefully remove baked waffle. Repeat with remaining batter. For best results, serve immediately. However, you may keep waffles warm in a 200°F (95°C) oven until ready to serve.

\* We recommend using setting #3 to achieve a golden brown baked waffle. Adjust the browning control if you prefer lighter or darker waffles.

### Nutritional information per waffle:

Calories 268 (43% from fat) • carb. 32g • pro. 7g  
• fat 13g • sat. fat 2g • chol. 57mg • sod. 371mg  
• calc. 175mg • fiber 1g

\* May use puréed apricots, peaches, pears, plums, or strawberries.

## BANANA CHIP WAFFLES

Sprinkle with powdered sugar for breakfast or top with a scoop of ice cream for an afternoon snack.

Makes eight 6½ inch (1.25 cm) round waffles

- 2 cups (500 ml) all-purpose flour
- 2 tablespoons (30 ml) sugar
- 1 tablespoon (15 ml) baking powder
- ½ teaspoon (2 ml) salt
- 1⅔ cups (400 ml) reduced fat milk
- 1 medium banana, mashed (½ cup [125 ml])
- 6 tablespoons (90 ml) vegetable oil
- 2 large eggs
- ½ cup (125 ml) mini chocolate chips

Place ingredients in a large mixing bowl and combine until well blended and smooth. Let batter sit 5 minutes before using. Preheat your Cuisinart™ Classic Waffle Maker on setting #3 \*(green indicator light will be illuminated when preheated).

Pour ½ cup batter onto the center of the lower grid; spread evenly using a heat-proof spatula. Sprinkle 1 tablespoon of minichips over batter. Allow batter to bubble for 5-10 seconds, then close cover of waffle maker. Indicator light will turn red. When light turns green again, waffle is ready. Open cover and carefully remove baked waffle. Repeat with remaining batter. For best results, serve immediately. However, you may keep waffles warm in a 200°F (95°C) oven until ready to serve.

\* We recommend using setting #3 to achieve a golden brown baked waffle. Adjust the browning control if you prefer lighter or darker waffles.

### Nutritional information per waffle:

Calories 334 (45% from fat) • carb. 39g • pro. 6g  
• fat 17g • sat. fat 4g • chol. 57mg • sod. 371mg  
• calc. 174mg • fiber 3g

\* For Banana Nut Waffles:  
Omit mini chocolate morsels. Add ½ cup (125 ml) chopped nuts (walnuts, pecans, almonds) to batter before baking.

## CLEANING AND MAINTENANCE

Once you have finished baking, remove plug from electrical outlet. Leave top lid open so grids begin to cool.

Never take your waffle maker apart for cleaning. Simply brush crumbs from grooves, and absorb any excess cooking oil by wiping with a dry cloth or paper towel.

You may clean the grids by wiping with a damp cloth to prevent staining and sticking from batter or oil buildup. **Be certain grids have cooled completely before cleaning.** If batter adheres to plates, simply pour a little cooking oil onto the baked batter and let stand approximately 5 minutes, thus allowing it to soften for easy removal.

To clean exterior, wipe with a soft dry cloth. Never use an abrasive cleanser or harsh pad. NEVER IMMERSER CORD, PLUG OR UNIT IN WATER OR OTHER LIQUID.

Any other servicing should be performed by an authorized service representative.

## STORAGE

Store with cord wrapped securely around base. For compact storage, stand waffle maker on opening end so Cuisinart logo is facing you.

## WARRANTY

### Limited Three-Year Warranty

We warrant that this Cuisinart product will be free of defects in material or workmanship under normal home use for 3-years from the date of original purchase.

This warranty covers manufacturer's defects including mechanical and electrical defects. It does not cover damage from consumer abuse, unauthorized repairs or modifications, theft, misuse, or damage due to transportation or environmental conditions. Products with removed or altered identification numbers will not be covered.

This warranty is not available to retailers or other commercial purchasers or owners.

If your Cuisinart product should prove to be defective within the warranty period, we will repair it or replace it if necessary.

For warranty purposes, please register your product online at [www.cuisinart.ca](http://www.cuisinart.ca) to facilitate verification of the date of original purchase or keep your original receipt for the duration of the limited warranty.

This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration or other damage to external or internal surfaces that does not impair the functional utility of the tool/gadget. This warranty also expressly excludes all incidental or consequential damages.

**If the appliance should become defective within the warranty period, do not return the appliance to the store. Please contact our Customer Service Centre:**

Toll-free phone number: 1-800-472-7606

Address: Cuisinart Canada

100 Conair Parkway

Woodbridge, Ont. L4H 0L2

Email: [consumer\\_Canada@conair.com](mailto:consumer_Canada@conair.com)

Model: WMR-CAC

To facilitate the speed and accuracy of your return, please enclose:

- \$10.00 for shipping and handling of the product (cheque or money order)
- Return address and phone number
- Description of the product defect
- Product date code\*/copy of original proof of purchase
- Any other information pertinent to the product's return

\* Product date code can be found on the underside of the base of the product. The product date code is a 4 or 5 digit number. Example, 110630 would designate year, month & day (2011, June 30th).

Note: We recommend you use a traceable, insured delivery service for added protection. Cuisinart will not be held responsible for in-transit damage or for packages that are not delivered to us.

To order replacement parts or accessories, call our Customer Service Centre at: 1-800-472-7606.

For more information, please visit our website at [www.cuisinart.ca](http://www.cuisinart.ca)

# Cuisinart®

SAVOR THE GOOD LIFE®



Coffeemakers  
Cafetières



Food Processors  
Robots  
culinaires



Toaster Ovens  
Fours  
grille-pain



Blenders  
Mélangeurs



Cookware  
Batteries de  
cuisine



Ice Cream  
Makers  
Sorbetières

Cuisinart offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances and cookware, and Savor the Good Life®.

Cuisinart offre une vaste gamme d'appareils de première qualité qui vous facilitent la tâche plus que jamais dans la cuisine. Faites l'essai de nos autres appareils de comptoir et batteries de cuisine, et Savourez la bonne vie<sup>MC</sup>.

**[www.cuisinart.ca](http://www.cuisinart.ca)**

©2011 Cuisinart Canada  
100 Conair Parkway  
Woodbridge, Ont L4H 0L2

[www.cuisinart.ca](http://www.cuisinart.ca)  
Consumer Call Centre Email: /  
Centre d'appel des consommateurs:  
[Consumer\\_Canada@Conair.com](mailto:Consumer_Canada@Conair.com)  
1-800-472-7606

Any trademarks or service marks of third parties referred to herein are the trademarks or service marks of their respective owners.

Toute autre marque de commerce ou de service mentionnée aux présentes sont les marques de commerce ou de service de leurs propriétaires respectifs.

Printed in China/ Imprimé en Chine  
11CC121996

IB-4006B-CAN